

Rear Compartment Heater

Your vehicle is fitted with a compact and economical supplementary heater for the rear compartment.

The heater runs using diesel fuel from the vehicle's fuel tank. Consumption ranges from as little as 0.10 litres of fuel per hour on the lowest setting, up to 0.28 litres on full power (0.022 to 0.061 Imp Gallons respectively) therefore your fuel economy should not be adversely effected.

The heater is not designed for long term continuous operation - when the vehicle is up to temperature, the vehicle's own heating should be able to maintain temperature throughout the cabin so the unit can be switched off.

The heater is operated using the rotary knob control attached to the dashboard. The heater can be turned on by rotating the control knob in a clockwise direction. The green light illuminates when the heater is on.



You can adjust the required temperature with the control knob. The left-hand end stop corresponds to approximately 5°C of heat and the right-hand end stop approximately 35°C of heat.

The heater can be turned off by rotating the knob in an anti-clockwise direction back to the '0' position.

Please note, the fan inside the heater will continue to run for a period of time after the heater is switched off in order to cool the unit. The longer and hotter it has been running, the longer this period is.

The air from the unit can be directed using the rotating outlet hood.

Air exiting the hood can be extremely hot.



Caution
Hot Air

Important Safety Notes

Please read and understand the full operating instructions for your heater.

Do not block the inlet or outlets of the heater - doing so will prevent correct operation.

Do not place luggage or other items on top of the heater as this may damage the unit or cause a fire.

Do not use the heater continuously - switch it off when a comfortable temperature is reached.

Do not direct hot air straight at passengers.

In the event of an error, the green indicator light on the rotary control knob will flash. In the unlikely event of a fault occurring, switch the heater off and contact us (see details below).

If you have any questions about your vehicle, please do not hesitate to call us on **01924 442386** or email customerservices@bristolstreetversa.com